

The Original Bank-Ease Planer™

It's not everyday that a passion and a practical pursuit converge into a great product... but here is one that has done just that.

Two years in development **The Original Bank-Ease Planer™** is the brain child of Robyn Moulder. A Southern Oregon native, Robyn has been fishing the Pacific Northwest most of his life. **The Original Bank-Ease Planer™** was born of necessity.

Weighing just over 8 ounces this product allows bank fishermen and boat fishermen alike the ability to get their line out and away from them and keep their line in place with precision.

Good for any type of fish **The Original Bank-Ease Planer™** has been instrumental in catching dozens of fish... Robyn's first catch using the planer was a 5.5 pound Cutthroat Trout. One of our customers called telling us about the dozen (12) Steelhead he caught around the Spokane Washington area while using **The Original Bank-Ease Planer™**.

The Original Bank-Ease Planer™ allows you to use any size and style tackle you choose... and supports up to a K16 KwikFish™.

* KwikFish™ and K16™ are trademarks of Luhr Jensen & Sons, Inc.

Learning to use this product requires practice! The first time you use this product will be similar to when you learned to cast.

The Original **Bank-Ease Planer™**

"IT REALLY PUTS YOU OUT THERE!"

Moulder

The Original **Bank-Ease Planer™**

"IT REALLY PUTS YOU OUT THERE!"



Trolls your Kwikfish™ or other lures from bank or boat

Moulder, LLC
www.moulder-inc.com
sales@moulder-inc.com • 541-941-0330
PO Box 782
Rogue River, Oregon 97537
USA

Bank-Ease Planer™ Features






- Trolls your lure (bait) from bank or boat
- Holds steady in slow or fast current
- Side planes from either side of river
- Uses your existing tackle
- Releases your line when fish strikes
- Handles up to K16 KwikFish™
- Can use bait, plugs, spinners, flies

How to set-up your Bank-Ease Planer™


PACKAGE CONTENTS:

- | | |
|------------------------|-------------------------|
| (1) Planer Skid | (5) Swivels |
| (1) Outrigger | (1) Tow Line Speed Clip |
| (1) Tail Hook | (2) Shower Clips |
| (1) Quick Release Clip | (1) Allen Wrench - 5/32 |
| (6) Split Rings | 75' Tow Line & Handle |

1. Unpack parts
2. With Planer pointed upstream, attach outrigger angled down to opposite side from bank. (Picture A & B)
3. Tighten screw with Allen wrench provided, DO NOT over tighten, just snug (don't forget to keep the wrench with you!). (Picture C)
4. Insert tail hook and tighten set screw with Allen wrench, DO NOT over tighten. (Picture D & E)
5. Attach tow line speed clip to Planer.
6. Use shower clip to attach tow line to bank or boat (NOT to your person!).




OFFSHORE RELEASE METHOD



1. Feed fishing line through split ring swivel, to line swivel, then lure snap
2. Insert split ring with swivel into quick release clip > split ring should be held 1/3-1/2 way into quick release clip
3. Release with both tow line & fishing line attached
4. Let out planer and lure at matching speed
5. Keep lure close to planer until in position then allow lure to dive, trail behind

CAST-OVER METHOD



1. Flip guide wire with lead weight over front of planer
2. Release planer with planer line attached
3. When positioned in current, tie off planer line to bank or boat (NEVER yourself)
4. Cast fishing lure 10 feet ahead of planer guide wire and 10-15 feet beyond planer board

Note: Fishing line will ride up on guide wire and catch tail hook.

Tune tail hook by bending slightly to the back for lighter tackle or to the front for heavier tackle.

CAUTION: DO NOT attach this product to your person when fishing! Remember to be courteous to others around you.